

Rev.	ECO	Description	Checked	Approval	Date
01	85-018	Initial Release			

**IS-300 SERIES
 PRECISION MOTION TRACKER
 USER MANUAL**

Dwg. No. 85-05001.01


Revision 01
 February 13, 2002



IS-300 Orientation Tracking System



User Manual for Firmware v3.0 and above



INTERSENSE

Contacting InterSense

Please do not hesitate to contact us for any reason. We are here to help and we value your business.

InterSense Inc.
73 Second Avenue
Burlington, Massachusetts 01803
USA

Telephone (781) 270-0090 Fax (781) 229-8995 email: info@isense.com

Regulatory Statements and Approvals



United States

FCC Part 15, Subpart B, Class A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Europe

EN60950
EN55022, Class A
EN50082-1

Warning


This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Trademarks

InterSense™, InertiaCube™, GEOS™ are trademarks of InterSense Inc. All other trademarks are the property of their respective owners.

Patents

The label below identifies the protection granted by the Government of the United States to InterSense for its products:



Precautionary Statements



Do not attach InertiaCube™ sensors to the system while the electrical power is applied.



Any changes or modifications not expressly approved by InterSense will void the user's authority to operate the equipment.



Do not drop or otherwise shock the InertiaCube or it can be permanently damaged.



Do not bend, twist, pull strongly or tamper in any way with any part of the IS-300 cabling.



Take care to avoid electric shocks. Do not plug-in or unplug the power supply with wet hands.



Please see Appendix C for Health and Safety warnings and guidelines

Table of Contents

Subject	Page
1. Theory of Operations	6
1.1 InertiaCube™ Integrated Inertial Instrument	6
1.2 3-DOF Gyroscopic Earth-stabilized Orientation Sensing (GEOS™)	7
2. Specifications and performance characteristics	9
3. Setting up your new IS-300	
3.1 IS-300 Components	11
3.2 Setting up the hardware	13
4. ISDEMO: Testing and configuring the IS-300	
4.1 Getting started	16
4.2 File Options	18
4.3 Communications	20
4.4 Parameter Options	21
4.4.1 Tracker System Parameters	21
4.4.2 Station and Sensor Parameters	22
4.5 Display Options	25
4.6 Tools Options	27
4.7 Window Management Commands under DOS	29
5. Interface communication protocol	
5.1 FASTRAK™ ¹ commands	30
5.1.1 Supported Fastrak™ Commands	30
5.1.2 Fastrak™ commands implemented for compatibility only	36
5.2 InterSense specific commands	37
5.2.1 System Configuration Commands	37
5.2.2 InterSense-specific Station Parameters	38
5.2.3 InertiaCube Assignment Commands	40

¹ FASTRAK™ is a registered trademark of Polhemus, Inc.

5.3	Records returned from the tracker to the host	41
5.3.1	Format Considerations	42
5.3.2	Fastrak™ System and Data Records	46
5.3.3	InterSense-specific Records	

Appendices

A.	Frequently Asked Questions (FAQ)	49
B.	Troubleshooting	51
C.	Health and Safety warnings and guidelines	52
D.	Interface Protocol Commands – Quick Reference	54
E.	Index of Terms	56

1 Theory of Operations

Congratulations for buying the finest orientation tracker on the market! This technology offers you several advantages:

- Very low latency
- Unlimited range
- Prediction based on directly sensed motion derivatives
- Smooth, jitter-free tracking

The IS-300 is an inertial 3-DOF (Degree of Freedom) orientation tracking system. It obtains its primary motion sensing using a miniature solid-state inertial measurement unit (called an InertiaCube™) which senses angular rate of rotation, gravity and earth magnetic field along three perpendicular axes. The angular rates are integrated to obtain the orientation (yaw, pitch, and roll) of the sensor. Gravimeter and compass measurements are used to prevent the accumulation of gyroscopic drift.

1.1 InertiaCube™ integrated inertial instrument

The InertiaCube is a monolithic part based on micro-electro-mechanical systems (MEMS) technology involving no spinning wheels that might generate noise, inertial forces and mechanical failures. The InertiaCube simultaneously measures 9 physical properties, namely angular rates, linear accelerations, and magnetic field components along all 3 axes. Micro-miniature vibrating elements are employed to measure all the angular rate components and linear accelerations, with integral electronics and solid-state magnetometers. The magnetometers are included for optional yaw drift correction in the sourceless inertial orientation mode only. The geometry and composition of these elements are proprietary, but the functional performance of the multisensor unit can be understood sufficiently by reference to the equivalent diagram in Figure 1.

Figure 2 illustrates the basic physical principal underlying all Coriolis vibratory gyros. Suppose that the tines of the tuning fork are driven by an electrostatic, electromagnetic or piezoelectric drive to oscillate in the plane of the fork. When the whole fork is rotated about its axis, the tines will experience a Coriolis force $\underline{F} = \underline{\omega} \times \underline{v}$ pushing them to vibrate perpendicular to the plane of the fork. The amplitude of this out-of-plane vibration is proportional to the input angular rate, and it is sensed by capacitive or inductive or piezoelectric means to measure the angular rate.

By way of comparison, a conventional inertial measurement unit (IMU) senses 6 of these properties using 6 separate instruments (3 rate gyros and 3 linear accelerometers) each of which by itself would typically be larger, heavier, and more expensive than an InertiaCube. Unlike conventional rate gyro and accelerometer instruments, which must be carefully aligned on a




Figure 1: Functional diagram of InertiaCube




Figure 2: Principle of Coriolis vibratory Gyroscope

precision machined triaxial mounting block, the InertiaCube is a monolithic device with its orthogonal outputs factory calibrated to precise alignment. Being a digital device, the InertiaCube cabling and connectorization is relatively non-critical, and the cables can be extended up to 30 feet without fear of contaminating sensitive analog signals. The power consumption of the InertiaCube is 30 mA at 9V, which makes it suitable for prolonged operation from a small battery in future wireless applications. Figure 3 shows an InertiaCube next to a floppy disk for scale.



Figure 3: InertiaCube

1.2 3-DOF Gyroscopic Earth-stabilized Orientation Sensing (GEOS™) algorithms

Figure 3 shows the processing which is used to compute orientation using this sensor configuration. The basic computation of orientation from gyroscopic angular rates (in the top line of boxes) provides the very rapid dynamic response and high resolution of the system. The accelerometers and magnetometers are used to stabilize the orientation to the earth's gravitational and magnetic fields, thus eliminating the gradual but unbounded accumulation of gyroscopic drift errors. The Kalman filter uses an ever-evolving adaptive algorithm to discard the portion of the accelerometer measurements which are due to actual motion instead of gravity. This is a very important step, because otherwise horizontal accelerations would result in very large

transient pitch and roll errors known as “slosh”. The low cost sourceless trackers used in early consumer HMDs are inclinometer/compass devices, and are thus intrinsically slosh-prone to the point of being uncomfortable to use.





Figure 3: GEOS mode tracking algorithm

In GEOS mode, the reference frame (hereafter referred to as Navigation frame or Nav frame or N frame) is the locally-level geographic frame with its x-axis pointing north, y-axis east, and z-axis pointing down. The Euler angles reported by the tracker can be described as a sequence of rotations applied to the InertiaCube starting with its body axes initially aligned with the Nav frame axes and resulting in the current orientation. The sequence starts with a rotation by (+yaw) about the Z axis, followed by a rotation by (+pitch) about the new Y axis (i.e. body frame axis), followed by a rotation by (+roll) about the new X axis (i.e. body frame x axis)



The line from the magnetic field sensor outputs of the InertiaCube to the Kalman filter is a dotted line to indicate that the use of the magnetometers may optionally be disabled. The accelerometer measurements are sufficient to correct all the drift in pitch and roll, and the geomagnetic compassing function is only used to correct drift in yaw. In many fly-through applications absolute yaw referenced to magnetic north is not important and relative yaw tracking is sufficient. This is the case when the user can turn to face an object or rotate the virtual world to bring that object into view. In these situations it may be desirable to turn magnetic yaw compensation off if there are large variations in the direction of magnetic north over the tracking area. With the compassing turned off, the yaw value will drift a few degrees per minute. This drift is too slow to notice while it is happening, but the cumulative yaw error may eventually become noticeable if the user is seated in a fixed chair, and then it may be necessary to send a Heading Boresight command. When yaw compensation mode is disabled,

the Nav frame axes are aligned instead to pseudo-north, pseudo-east, and down, where pseudo-north is simply the direction the InertiaCube x-axis was facing on power-up or after a Heading Boresight command.

The Perceptual Enhancement Algorithm (PEA) indicated with dotted lines is an option provided for HMD tracking and similar applications which is designed to make the output data minimize perceivable errors rather than minimize mean square errors. Because the human observer is more sensitive to jitter and drift when still or moving slowly, the PEA uses adaptive filtering to preferentially suppress these effects as the head slows down. Interestingly, the PEA only filters the corrections to orientation made by the error estimator, and not the orientation signals themselves. Therefore, the trade-off is increased dynamic error, and not increased latency. If a head at rest suddenly makes a rapid movement, there will be no additional latency imposed by the PEA in the all-important head-motion-to-visual-feedback sensorimotor loop. The Perceptual Enhancement is a constantly evolving family of fuzzy rule-based algorithms which have been quite successful in eliminating most perceivable jitter and drift without introducing any latency. For information on controlling the PEA see the Perceptual Enhancement Level command in sections 4.4.2 and 5.2.2.

2 Specifications and Performance Characteristics

Performance Specifications

Degrees of Freedom	Yaw, pitch, and roll
Angular Range	All orientations
Maximum Angular Rate:	1200°/sec
Angular Resolution:	0.02° RMS
Angular Accuracy:	1.0° RMS
Dynamic Accuracy:	3.0° RMS
Update Rate:	up to 500Hz


	IS-300	IS-300 Pro
Prediction:	NA	0-50ms
Number of InertiaCube Sensors:	1	up to 4
Interface:	RS-232C with selectable baud rates to 115, 200	
Protocol:	Compatible with industry-standard protocol (FASTRAK™)	

Physical Specifications

Power: 12 VDC, 8.6A
 Operating Temperature: 0 to 50°C (32°F to 122°F)
 Storage Temperature: -20 to 70°C (-4°F to 158°F)

	InertiaCube Sensor	Base Unit Signal Processor
Dimensions	1.06" x 1.34" x 1.2"	5.08" x 5.25" x 1.5"
Weight	2.1 oz.	15 oz.
Cable	10' extendible to 30'	NA

Block Diagram



Compatibility

The InterSense IS-300 is compatible with all industry leading software and hardware, including products from:

- Virtual Research •Superscape •Sense8 •MetaVR •Division
- Kaiser Electro-Optics •Softimage •Multigen •nVision •Xtensory
- Thomson T&S

3 Setting up your new IS-300

3.1 IS-300 Components



IS-300 Base Unit

The base unit is the processing engine of the IS-300 system. It has the following connections:

- InertiaCubes (up to 4) via cable attached to the InertiaCubes
- Power via 12V DC power supply.
- User's Computer via null modem RS232 cable

The base unit should be installed in a clean, dry environment.

InertiaCube sensors

The InertiaCube orientation sensors come with 10-foot cables that plug into the IS-300 Base Unit.

NOTE: the InertiaCube sensor is a precision instrument. Care must be taken when handling this device. Most of our customers attach the InertiaCube to devices that are more fragile than the InertiaCube and, hence, require that the whole system must be handled carefully. Although the product can withstand the normal wear and tear experienced by a premium HMD or other device, abrupt actions such as dropping it, or banging it against another object can permanently damage the InertiaCube.

Software

The following software is included with the system and is explained in great detail in Section 4:


1. ISDEMO32.EXE - For Windows95/98 and NT
2. ISDEMO.EXE - DOS version of ISDEMO program
3. ISDEMO.HLP - A file which contains help text also reprinted here

UNIX version of ISDEMO is currently not available. To obtain sample source code for DOS, Windows 95/NT or UNIX, please contact InterSense.


3.2 Setting up the Hardware

InertiaCube placement

The InertiaCube is typically screwed or bolted to the object it is tracking. As best as possible, locate the InertiaCube level to the ground in relation to its actual position during use:



Optimally, you would mount the InertiaCube onto a base plate. In cases of anticipated vibration or physical shock, it is recommended that rubber mounting pads be used. The mounting holes for the InertiaCube are illustrated below:



The InertiaCube comes with a 10' cable attached. This cable plugs into the front panel of the Base Unit.

The range of the InertiaCube is theoretically unlimited and is only restrained by the length of the cable that attaches it to the Base Unit. A length of 10 feet is standard on all orders. Lengths above 30 feet have been tested without problem, but they are subject to loss of signal strength; consult with InterSense.

Base Unit Set-up

1. Make sure the unit is turned off before connecting any cables.
2. Connect the InertiaCube(s) to the front of the Base Unit.
3. Plug in the power cord.
4. Connect the RS232 cable between the Base Unit and the Host Computer.
5. Select baud rate using mode switch as described below.

Set the power mode switch to “on”. The “power on” LED on the front panel will turn on. The four (IS-300 Pro) LED lights on the front panel of the Base Unit to the left of the InertiaCube plug-in locations will flash in sequence for a few seconds then stop. Each LED corresponds to the InertiaCube plug-in pattern to the right (i.e., upper right hand LED is for the upper right hand InertiaCube plug-in # 4). When a particular InertiaCube is in motion, the corresponding LED will flash to acknowledge this. IS-300 single sensor tracker has only one sensor connector and one LED.

Baud Rate

The Base Unit has a switch located on the back of the unit. This gives you the option of choosing one of four baud rates:

9,600	(mode 0)	
19,200	(mode 1)	<i>these correspond to the</i>
38,400	(mode 2)	<i>mode switch at last</i>
115,200	(mode 3)	<i>power up</i>

Note: you must power cycle the system (power-down/power-up) after changing the mode.

Tracker Use Guidelines

- Keep the InertiaCube(s) still (i.e., sitting on a table) for the entire boot-up period, whenever the tracker configuration is changed, and during any boresight operations.
- It is recommended, though not required, that you wait for the InertiaCube to warm up (it achieves optimal performance after warming up for at least 15-20 minutes).
- The InertiaCube is tuned for normal head motion. Avoid shaking/vibration. Remember, this precision instrument uses angular rate sensors which sense smooth, regular movement very well.

If you keep these guidelines in mind, your IS-300 will deliver superb performance.

4 ISDEMO: Testing the IS-300

ISDEMO is included as a test/diagnostics/configuration tool. With it you can test all the features of your tracker. You can also use it to set and save tracker configurations.

Software included with your tracking device includes the following:

- | | |
|-----------------|---|
| 1. ISDEMO32.EXE | Win32 version. To be used under Windows95/98 and NT |
| 2. ISDEMO.EXE | DOS version of ISDEMO program |
| 3. ISDEMO.HLP | A file which contains help text also reprinted here |

ISDEMO provides a convenient graphical interface that can configure most of the tracker parameters. There are, however, some features it does not support. These features can be configured by sending single line commands through the serial port. See the section titled “Interface Communication Protocol” for descriptions of all the available commands.

4.1 Getting Started

Create a directory on your hard drive where you would like the program to be installed. Copy all files and directories from the floppy disk to that location (xcopy a:\ c:\isdemo\s).

When running DOS version without a mouse use following keys to control window functions:

- | | |
|---------|--|
| Alt+F10 | causes the active window to be maximized/restored. |
| Alt+F4 | generates the window close request. |
| Alt+F2 | causes a redraw in all open windows. |
| Alt+F1 | circulates windows. |


If mouse is available you can also use Alt+drag to resize the window on which the mouse button is pressed.

Important: Please note that ISDEMO does not save any tracker parameters to the hard disk of your computer. All settings displayed in various configuration screens are requested and received from the tracker every time the screen is displayed. All changes are immediately converted to commands, sent to the tracker, and then confirmed.

Using the ISDEMO

The first screen you'll see is the hardware selection window (shown below). The program creates a different interface depending on the tracker model selected.

ISDEMO can detect the tracker model automatically. Serial communication must first be established with the tracker to utilize this function. Use the *Autodetect* option in the *Communications* menu to detect port and baud rate parameters if you have trouble setting them manually.



IS-300

The IS-300 is a 3-Degree Of Freedom (DOF) tracker. It obtains its primary motion sensing data using a miniature solid-state inertial measurement unit (InertiaCube) which senses angular rate of rotation, gravity and earth components along three perpendicular axes. The angular rates are integrated to obtain the orientation (yaw, pitch, and roll) of the sensor. Gravimeter and compass measurements are used to prevent the accumulation of gyroscopic drift.

IS-600

The IS-600 uses an InertiaCube to sense angular rate of rotation and linear acceleration along three perpendicular axes. The angular rates are integrated to obtain the orientation (yaw, pitch, and roll) of the sensor and the linear accelerations are transformed into a reference coordinate frame and double-integrated to keep track of changes in position (x, y, and z). Ultrasonic time-of-flight distance measurements are used to obtain a starting position and to correct any drift in the inertial position and orientation tracking.

IS-900The IS-900 is similar to the IS-600, except the roles of the SoniDiscs and ReceiverPods are reversed. Ultrasonic range measurements are made with respect to an array of SoniDiscs. The array is positioned over the required tracking area or on a wall behind the tracker or both. The SoniDiscs are triggered by infrared triggering codes, and they respond by emitting an ultrasonic chirp, which propagates through the air. Three ReceiverPods mounted in the tracker then detect this chirp. The ReceiverPods and associated electronics on the tracker measure the time-of-flight and thereby obtain range measurements from the camera to whatever SoniDiscs are nearby and visible.


Note:

You must select IS-300, or ISDEMO will not be able to correctly configure your tracker.

ISDEMO: Main window

ISDEMO has six primary menus in its main window:

- File
- Communications
- Parameters
- Display
- Tools
- Help



4.2 File options

The *File* menu (shown above) provides you with the following options:

- Select Hardware Device
- Boresight Current Station
- Unboresight Current Station
- Save Current Settings
- Load Power-up Settings
- Load and Save Factory Settings

Select Hardware Device

System Initialization window (also seen at initial start-up) is shown when *Select Hardware Device* is selected. Use this window to select or detect the tracker model connected to your computer.

Save Current Settings Sends ^K command to the tracker. This saves the current settings to nonvolatile memory in the tracker base unit. The next time the tracker is turned on these settings will be restored.

Load Power Up Settings Sends ^Y commands to the tracker. This restores the firmware to the power up condition. All changes made to the settings since power up or last ^K command are lost.

Load and Save Factory Settings


Sends W command to the tracker. This restores the system settings to the factory defaults. All changes made since power up or last ^K command are lost.

Boresight Current Station Sends the $B\{stationNum\}<>$ command to the tracker, where *stationNum* is the number of the currently displayed station. Please see section 4.2.7 for instructions on how to switch between stations. Please see chapter 5 for complete explanation of the boresight implementation.

Unboresight Current Station Sends the $b\{stationNum\}<>$ command to the tracker. This reverses the effects of boresight command.

4.3 Communications options

This menu allows you to set the communications port and the baud rate of the computer ISDEMO is running on to match the settings of the tracker.



Communications Port

Choose *Com1* or *Com2* (shown above). Some versions of ISDEMO may have *Com3* and *Com4* listed as well.

Baud Rate

You have the option of choosing one of four baud rates:

9,600	(mode 0)	
19,200	(mode 1)	<i>these correspond to the</i>
38,400	(mode 2)	<i>mode switch at last</i>
115,200	(mode 3)	<i>power up</i>


Autodetect Parameters

When chosen this option will automatically detect the port and the baud rate being used. The program attempts to establish communication by sending the *S* (status record request) command and waiting for a response for 2 seconds. If the status record is not received within that time the program tries again with the different communication parameters.




4.4 Parameter options

Parameters menu gives you access to the tracker configuration controls.



4.4.1 Tracker System Parameters



Output Mode

Polled or Continuous. In Polled mode data records are sent out only in response to a *P* command.

Data Format

ASCII (F command)

Numbers are returned in ASCII format. Each number has 7 ASCII characters: a sign, 3 digits, a decimal point and 2 more digits.

Binary (f command)


Floats are sent as 4 bytes of IEEE 32-bit floats. This can increase the data throughput by minimizing the size of the record.

4.4.2 Station and Sensor Parameters

The window shown below allows you to configure each station. IS-300 model trackers can support up to 4 stations. Performance is reduced as more stations are configured.


Before any data is displayed in this list, the program requests and then attempts to receive the configuration data from the tracker. If this fails for any reason, an error message is displayed and data in the list may not be reliable.

Some configuration parameters, like prediction, are only relevant when an InertiaCube is associated with a station. When none are, N/A (not applicable) is displayed.



Double clicking on the Station line or clicking the Change button will bring up the Station Configuration window where changes can be made.

Station Configuration window



Station ON/OFF

Whenever a station is ON a data record will be sent for it, even if no InertiaCube is assigned to it.

Compass

This turns the compass component of the InertiaCube on or off. When compass is off, yaw orientation component will accumulate error over time.

InertiaCube Number

InterSense trackers support up to 4 InertiaCubes. You must assign and InertiaCube to the station in order to track orientation.

Perceptual Enhancement Level

In order to provide the best performance for a large range of various applications, 3 levels of perceptual enhancement are available. None of the modes introduces any additional latency.

Mode 0 provides the best accuracy. The inertial tracker uses gyros to measure angular rotation rates for computing the sensor's orientation. To compensate for the gyroscopic drift, depending on the configuration, the tracker may use accelerometers and magnetometers to measure the actual physical orientation of the sensor. That data is then used to compute the necessary correction. In Mode 0 correction adjustments are made immediately, no jitter reduction algorithms are used. This results in somewhat jumpy output (not recommended for head tracking) but with lower RMS error. Use

this mode for accuracy testing or for any application that requires best accuracy.

Mode 1 provides accuracy similar to that of mode 0, with an addition of a jitter reduction algorithm. This algorithm reduces the accuracy by only a small amount and does not add any latency to the measurements.

Mode 2 is recommended for use with HMD or other immersive applications. The drift correction adjustments are made smoothly and only while the sensor is moving, so as to be transparent to the user.

Sensitivity Level

This setting is only used when Perceptual Enhancement Level is set to 2. It controls the minimum angular rotation rate picked up by the InertiaCube. Default is level 3. A value of 5 uses the maximum sensitivity to pick up rotations as slow as 0.25 degrees per second. Increasing sensitivity does not increase latency during normal movements. It may, however, result in some small residual movements for a couple of seconds after the sensor has stopped. If your application requires sensitivity greater than maximum provided by this control, you must use Perceptual Enhancement level 0 or 1 instead.

Prediction Value

InterSense tracker models IS-300 Pro and higher can predict motion up to 50 ms into the future, which compensates for graphics rendering delays and further contributes to eliminating simulator lag.

Commands sub-menu

Refresh Status

Program requests status records for all the parameters displayed in this dialog box. Settings are displayed as soon as they are received. If records are not received within two seconds a communication error is assumed.

Send Boresight Command

Sends boresight command to the station being configured.


Send Unboresight Command

Reverses the effects of the boresight command.

Send Reset Angles Command

Reverses the effects of the Alignment Reference Frame command.

4.5 Display Options



Start (and Stop) Displaying Data

To display position and orientation data being received from the tracker, use the *Start Displaying Data* option in the *Display* menu or press Ctrl-D. ISDEMO first attempts to establish communication and get all configuration information necessary to correctly interpret and display incoming data. If it fails to receive a reply to any of the status record requests it will still go into the display mode, but there may be no data to display or it may not be able to display the data correctly. If such errors are detected, stop the display by selecting *Stop Displaying Data* option in the *Display* menu or pressing Ctrl-X and check the connection.


Station Number

Allows you to choose which station is to be displayed.

Display Text

When this option is selected all status and some of the data records are displayed in text format in the sensor display area. To prevent graphics updates from taking over most of the processor time no more than 20 data records per second are displayed.

Please note that whenever your tracker is in continuous mode, records are displayed in the text window even when the display is off.




Numeric Display

Turns on/off the numeric readout for Pitch, Yaw, and Roll. This is useful when running on a very slow computer.

Synchronize to monitor


This option is only available in DOS version and is designed to reduce the flickering of the image during data display. It attempts to do all drawing between monitor refresh cycles. This, however, limits the frame rate to a maximum of 60 fps, and with numeric and analog display will likely reduce it to 30 or below, depending on the speed of your computer.

4.6 Tools Options



Send Command String

Send Command String allows you to send single line commands to the tracker. This tool is provided to allow control over the tracker parameters not supported in the menus and dialogs. For instance, you can use this function for test and debug purposes. Type in the command and press Enter or Return. The <CR LF> pair is automatically added to the end of the line before it is written to the serial port.




See Section 5 – Interface Communication Protocol for the complete list of all available commands.

Send Command File


This option allows you to send an entire file to the tracker over the serial port. This tool may be useful if you would like to keep a list of tracker configuration commands in a file. *Send Command File* opens a file selection dialog in which you can identify the file, directory and drive of a command file to be sent.

When creating a command file please enter commands one per line. It is not necessary to add CR and LF to any lines in the file.




System Information

This window provides a summary of the InterSense tracker system configuration



Data Capture/Playback Utility

ISDEMO has the ability to write the data it receives from the tracker to a file. To utilize this feature you must first specify the name and location of the output file. To start data collection select Record. The data is saved as is, so if you are planning to import these files to Excel or Matlab you must set the output format to ASCII. You can display previously recorded data through ISDEMO selecting Play.



Help Facility

Help in the ISDEMO is context sensitive. Selecting Help or pressing F1 will bring up the appropriate help subject.

4.7 Window Management Commands under DOS

The DOS version of ISDEMO does not have all the window management functionality of the Windows version.

- Alt+F10* Causes the active window to be maximized/restored.
- Alt+F4* Generates the window close request.
- Alt+F2* Causes a redraw in all open windows.
- Alt+F1* Circulates windows.
- Alt+drag* Is used to resize the window on which the mouse button is pressed.

To move a window, hold down the left mouse button over the window header and drag (same as in Windows).

Shortcut Keys

- F10* Activate menu (same as ALT key in Windows).
- Ctrl+Q* Closes current window.
- Ctrl+D* Start displaying sensor data.
- Ctrl+X* Stop displaying sensor data.

While the sensor position and orientation are being displayed, the cursor will blink and may be hard to follow. We recommend you use the keyboard commands instead.

5 Interface Communication Protocol

For IS-300 firmware version 3.01

Commands Sent from the Host to the Tracker

- <> Carriage return line feed pair- not needed for single character commands.
CR – ASCII value 13, LF – ASCII value 10.
- { } List of parameters required for command.
- [] List of optional parameters for command. Omitting them results in a query.

The IS-300 emulates most (but not all) of the commands in the Polhemus Fastrak™ protocol, thus it is possible to use the IS-300 with most applications without writing new driver code. There are also several additional commands added to access some of the advanced features of the IS-300 which do not have any counterpart in the Fastrak™ protocol.

5.1 Standard Fastrak™ Interface Commands

5.1.1 Supported Fastrak™ Commands

Data Record Request *P* Request a data record from all active stations.
Only used in polled mode.

Output mode *C* Put in continuous output mode.
c Put in polled output mode.
Default **Polled mode**

Alignment Reference Frame

A{stationNum},[Ox,Oy,Oz, Xx,Xy,Xz, Yx, Yy, Yz]<>

Sets the coordinate frame with respect to which outputs for that station will be reported. The coordinate frame is defined by a set three points. *Ox,Oy,Oz* defines the origin of the new coordinate system, *Xx,Xy,Xz* defines a point on the positive x-axis and *Yx, Yy, Yz* defines a point on the positive y-axis. If optional parameters are omitted, current values are returned.

Default X=North, Y=East, Z=Down, position origin is not relevant.

Reset Alignment Reference Frame

R{stationNum}<>
Resets reference frame to the default.

Boresight Reference Angles

G{stationNum},[yawref, pitchref, rollref]<>
Sets the boresight reference angles for the specified station. If set, these values are then used by the next Boresight command instead of current orientation. If optional parameters are omitted, current reference angles are returned.

Default 0,0,0

Boresight Compatibility Mode

MBF<> Switch system to Fastrak™ Compatible mode.

MBI<> Switch system to Firmware Version 2.x Compatible mode.

In firmware versions prior to 3.00 the *B{stationNum}<>* command was implemented as the Heading Boresight (see below) and full boresight was not available. To maintain compatibility with the user software written at that time, two Boresight Compatibility modes are available. In Fastrak™ Compatible mode *B{stationNum}<>* command executes full 3-DOF boresight and *MB{stationNum}<>* affects heading only. In the Firmware Version 2.x Compatible mode the meanings of these commands are reversed.

Default Firmware Version 2.x Compatible

Boresight

B{stationNum}<> (Fastrak™ compatibility mode)
MB{stationNum}<> (Firmware Version 2.x compatibility mode)

Boresight a station. If boresight reference angles have been specified by the *G{stationNum}[yawref, pitchref, rollref]<>* command prior to issuing of Boresight command then that orientation becomes the new reference point. The angles output by the tracker at that orientation become zero. Otherwise system uses current station orientation and that becomes the new reference line of sight. Please make sure that the object being tracked (like an HMD) is leveled and is pointing down the x-axis when boresighting a station.

Unboresight

b{stationNum}<> (Fastrak™ compatibility mode)
Mb{stationNum}<> (Firmware Version 2.x compatibility mode)

Unboresight a station. Reference angles are cleared for the specified station.

Heading Boresight

B{stationNum}<> (Firmware Version 2.x compatibility mode)
MB{stationNum}<> (Fastrak™ compatibility mode)

This command is used to define a user coordinate frame for orientation. The default orientation reference frame is a locally-level geographic frame with its x-axis pointing towards local magnetic north if the compass is on, or towards the direction the InertiaCube was facing at power-up, if the compass is off. This command takes the current heading and makes it the new direction of the x-axis. The *yaw* value at that point becomes zero. This command is similar to Alignment Reference Frame command, except it only affects orientation and not position output.

Heading Unboresight

b{stationNum}<> (Firmware Version 2.x compatibility mode)
Mb{stationNum}<> (Fastrak™ compatibility mode)

Clears the orientation coordinate frame changes produced by the Heading Boresight command.

Set Communication Parameters

o{rate,parity,bits,HHS}<>

Change the communication parameters

rate is one of 3,12,24,48,96,192,384,576,1152 (*rate* is multiplied by 100)

parity N = none
O = odd
E = even

bits 7 or 8

HHS (Hardware handshake)
0 = OFF
1 = ON

Default Baud rate depends on hardware 'mode' switch;

***Parity* N**

***bits* 8**

***HHS* OFF**

System Record Request

S Request a system status record to be sent.

Station Status

l{stationNum},[state]<>

set the *stationNum* on or off.

state 0 = OFF

1 = ON

Default Only station 1 is on

Output Units Control

U Sets output data record position units to inches.

u Sets the position units to centimeters. This command is not relevant to the IS-300.

Default U

System control

^K Save the current settings to nonvolatile memory.

W Restore the system settings to the factory defaults.

^Y Restart the firmware to the power up condition.

^S Suspend data transmission.

^Q Resume data transmission.

Caution: Sending *W* command will cause all the user configuration information to be lost.

Output record mode

F Put in ASCII output mode

f Put in Binary output mode.

Default F

Output record list settings

$O\{stationNum\},[p1],[p2],[p3],\dots,[pn]\langle\rangle$

Sets the output data list for *stationNum*. If optional parameters are omitted, a data record containing current output list settings for the station is returned.

Item	Description	Output Format
0	ASCII space character	- 1 ASCII byte
1	ASCII CR, LF pair	- 2 ASCII bytes
2	x, y, z position coordinates	- 3 floats
4	yaw, pitch and roll Euler angles	- 3 floats
5	X-axis direction cosines	- 3 floats
6	Y-axis direction cosines	- 3 floats
7	Z-axis direction cosines	- 3 floats
11	orientation quaternion	- 4 floats
16	stylus switch status (always 0)	- 1 byte (ASCII or binary)
18	x, y, z in 16 bit binary format	- see next page
19	yaw, pitch and roll in 16 bit binary format	- see next page
20	quaternion in 16 bit binary format	- see next page
21	time stamp, in selected time units	- see section 5.3.2


Default 2,4,1

Note:

IS-300 can't track position. The reason position is present in the default output record list is to maintain compatibility with software written to work with Fastrakä devices.

Data Item 4 – Euler Angles.

The Euler angles are defined as rotations about Z, then Y, then X in body frame. Angles are returned in degrees.



Data Items 5, 6, 7 – Direction Cosines.

X-axis, Y-axis and Z-axis direction cosines can be used to construct a 3x3 rotation matrix.

$$\begin{pmatrix} x1 & x2 & x3 \\ y1 & y2 & y3 \\ z1 & z2 & z3 \end{pmatrix} \begin{array}{l} \text{X direction cosines.} \\ \text{Y direction cosines.} \\ \text{Z direction cosines.} \end{array}$$

This matrix can also be constructed from Euler angles:

$$\begin{pmatrix} \cos(P)\cos(Y) & \sin(R)\sin(P)\cos(Y) - \cos(R)\sin(Y) & \cos(R)\sin(P)\cos(Y) + \sin(R)\sin(Y) \\ \cos(P)\sin(Y) & \sin(R)\sin(P)\sin(Y) + \cos(R)\cos(Y) & \cos(R)\sin(P)\sin(Y) - \sin(R)\cos(Y) \\ -\sin(P) & \cos(P)\sin(R) & \cos(P)\cos(R) \end{pmatrix}$$

Data Item 11 – Orientation Quaternion.

Quaternion is returned as $q = [w, x, y, z]$. Quaternion to rotation matrix conversion can be accomplished using the following formula:

$$\begin{pmatrix} 1-2y^2-2z^2 & 2xy-2wz & 2xz+2wy \\ 2xy+2wz & 1-2x^2-2z^2 & 2yz-2wx \\ 2xz-2wy & 2yz+2wx & 1-2x^2-2y^2 \end{pmatrix}$$

Data Items 18, 19, 20 – 16 bit binary format.

16 bit binary format can be used in applications requiring the fastest possible serial I/O. Each floating point number is stored in 2 bytes with only 14 bits containing actual data. This results in lower accuracy than the standard IEEE floating point format.

Data is 2's-complement. The first byte of the data set has its high-order bit set to 1, all others have them set to zero. This can be used for data synchronization. Data is returned low-order byte, then high-order byte. Use the following code sample as an example on how to decode this format:

To decode Euler angles:

```
lo = (dataRecord[3] & 0x007F);  
hi = (dataRecord[4] & 0x007F);  
int14bit = (lo << 2) | (hi << 9);  
result = (float) int14bit * 180.0 / 32768.0;
```

Resulting number represents orientation and has a full range of ± 180.0 (-180.0 to $+179.978$) degrees.

To decode Orientation Quaternion:

```
lo = (dataRecord[3] & 0x007F);  
hi = (dataRecord[4] & 0x007F);  
int14bit = (lo << 2) | (hi << 9);  
result = (float) int14bit * 1.0 / 32768.0;
```

Resulting quaternion value has range of ± 1.0 .

5.1.2 Fastrak™ commands implemented for compatibility only.

Hemisphere

H{stationNum},{p1,p2,p3}<>

Sets the tracking hemisphere for a magnetic tracking system. Because InterSense trackers are not magnetic the parameters are ignored. However, they can be set and then queried for compatibility with software such as Multigen Smart Scene. If optional parameters are omitted, a data record containing current Hemisphere settings for the station is returned.

Default 1,0,0

5.2 InterSense Specific Commands

All InterSense specific commands start with the letter M (for “Manufacturer-specific”) and must be completed by a CR,LF pair.

5.2.1 System Configuration Commands

Time Units

The time stamp recorded is the time when the tracker data was collected from the hardware. The time index is set to zero when tracker is first turned on.

MT<> Sets the units for the data record time stamp to *milliseconds*.

Mt<> Sets the units for the data record time stamp to *microseconds*.

Default T

Set Current Time to Zero

MZ<> This command sets current time index of the tracker to zero.

InterSense System Status Record Request

MS<> Request the manufacturer-specific system status record. This is information about parameters which are specific to the InterSense product, additional to the standard system status information obtained using the S command.

5.2.2 InterSense-specific Station Parameters

InterSense Station Status Record Request

Ms{stationNum}<>

Request an individual sensor status record for *stationNum*. This is information about parameters which are specific to the InterSense product.

Compass Heading Correction

MH{stationNum}<>

Turns on the *stationNum*'s compass heading correction. To operate effectively the magnetic field in your workspace needs to be homogeneous (this can be difficult to arrange in a typical work environment).

Mh{stationNum}<>

Turns off the *stationNum*'s compass heading correction. There will be slow drift in the yaw direction only.

Default H

Prediction Interval

Mp{stationNum},[interval]<>

Sets the time-interval of prediction for *stationNum*. *Interval* is an integer number of time in milliseconds. Suggested range is 0-50ms. This parameter is used for both position and orientation prediction. If optional parameter is omitted, current prediction value is returned.

Default 0

Perceptual Enhancement Level

MF{stationNum},{Mode}<>

In order to provide the best performance for a large range of various applications 3 levels of perceptual enhancement are available. None of the modes introduces any additional latency.

Mode 0 provides the best accuracy. The drift correction adjustments are made immediately, no jitter reduction algorithms are used. This results in somewhat jumpy output (not recommended for head-tracking) but with lower RMS error. Use this mode for accuracy testing or for any application which requires best accuracy.

Mode 1 provides accuracy similar to that of mode 0, with an addition of a jitter reduction algorithm. This algorithm reduces the accuracy by only a small amount and does not add any latency to the measurements.

Mode 2 is recommended for use with HMD or other immersive applications. The drift correction adjustments are made smoothly and only while the sensor is moving, so as to be transparent to the user.

Default 2

Rotational Sensitivity Level

MQ{stationNum},[Sensitivity Level]<>

Adjusts rotational sensitivity of a station. These settings are only applicable when the Perceptual Enhancement Level is set to 2. *Sensitivity Level* is an integer 1 to 5 where 1 is the lowest and 5 is the highest sensitivity. If optional parameter is omitted, current value is returned.

Default 3

5.2.3 InertiaCube Assignment Commands

Associate InertiaCube with a Station

MCI{station number},[InertiaCube number]<>

This command assigns an InertiaCube to a station. If the second parameter is omitted current assignment information is returned. The InertiaCube number can be 1 to 4 and is the same as the number of the connector on the tracker. This command does not take effect until explicitly activated by the *MCE<>* command.

Disassociate InertiaCube from a Station

MCi[stationNum, InertiaCube number]<>

This command removes an InertiaCube from the station configuration. The InertiaCube number can be 1 to 4 and is the same as the number of the connectors on the tracker. If the station number and the InertiaCube number are not associated in the current this configuration command is ignored. If both parameters are omitted all station to InertiaCube associations are cleared. This command does not take effect until explicitly activated by the *MCE<>* command.

Apply New Configuration

MCE<>

This command reconfigures the system with the new InertiaCube and PSE information. A Configuration Session is the period during which the station and InertiaCube assignment commands are received and accepted. Configuration session starts when the first *MC* command arrives. *MC* commands are saved but not applied to the system configuration until the *MCE<>* command is received. This command executes all *MC* commands received since the start of the Configuration Session and computes the new system state.

Cancel Configuration Session

MCx<>

Cancel the configuration session command. All *MC* commands received during the session are discarded.

5.3 Records Returned from the Tracker to the Host

5.3.1 Format Considerations.

Record Headers.

The first byte of each record is used to identify its type.

- 0 – Data record.
- 2 – Fastrak™ status record.
- 3 – InterSense manufacturer-specific status record.

Floating Point Numbers.

Floating point numbers can be returned as IEEE 32 bit floats or as ASCII numbers in *X.xf* notation, where:

- X* is the total number of characters used to represent the float.
- x* is the number of digits after the floating point.
- f* symbol indicating that number is a float.

For example, number -42.6 in *10.4f* format would look as follows: “ -42.6000”

Status Record Hexadecimal Character Decoding.

System Status, Manufacturer Status, and Manufacturer Station records use Hexadecimal Characters to encode status data. Each character can be 0 to F and can encode 4 bits. Logical AND operator can be used to test specific bits. Please see following code example:

```
unsigned short byte1, byte2, byte3;
char hexChar[2];

hexChar[1] = 0x00;

hexChar[0] = statusRecordBuffer[3];
sscanf(hexChar, "%x", &byte1);
hexChar[0] = statusRecordBuffer[4];
sscanf(hexChar, "%x", &byte2);
hexChar[0] = statusRecordBuffer[5];
sscanf(hexChar, "%x", &byte3);
```

5.3.2 Fastrak™ System and Data Records.

Data Record

This record is sent in response to a *P* command in polled mode or continuously in continuous mode. A separate data record is sent for each active station. The list of data items in each station record depends on how the list was set up with the *O* command. For most of the commonly used data list items, the format depends on commands *F*, *f*, *U*, *u*, *MT*, *Mt*.

O{*stationNum*}{*status*}{*dataItem1,dataItem2,...*}

stationNum

A number from 1 to 4.

status An ASCII space character. This status byte is currently unused.

dataItemX

ASCII In ASCII numbers, set with the *F* command, any numbers returned as floats are returned as ASCII numbers. Each number is 7 ASCII characters: a sign, 3 digits, a decimal point and 2 more digits. If programming in C use *scanf*("%7.2f", &*value*) to read them.

Binary In binary mode, set with the *f* command, the floats are sent as 4 byte IEEE 32-bit floats.

Time Stamp 32 bit floating point number

ASCII In ASCII mode it is allowed 14 characters and is displayed as an integer (digits after the floating point are ignored).

Binary In binary mode it is returned as a 32 bit float.

Binary16 mode

Set by selecting 18, 19 and/or 20 only with the *O* command. This is the fastest way to get data but the most difficult to decode and the least accurate.

Example:

For the default data record *O1,2,4,I<>* in ASCII mode *F*. The output record set for the active stations 1 and 2 would look as follows:

```
'01 1.23 41.83 12.18 13.04 76.11 34.12CRLF'  
'02 23.01 -452.94 0.01 -1.01 23.32 12.34CRLF'
```

For station 1: x=1.23, y=41.83, z=12.18, yaw=13.04, pitch=76.11 and roll=34.12
For station 2: x=23.01, y=-452.94, z=0.01, yaw=-1.01, pitch=23.32 and roll=12.34

System Status Record

This record is sent in response to the *S* command. It contains system wide status information. Some of the information in the status record must be bit decoded.

2IS{statusRecord}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type, '2'
2	Station Number. Always '1'
3	Sub-Record type, 'S'
4	Config Hex Char 0
5	Config Hex Char 1
6	Config Hex Char 2
7-9	BIT error. Currently unused
10-15	Blank
16-21	Firmware version ID
22-53	System Identification
54-55	CR, LF

To decode each of the Config bytes

Config Hex Char 0	Unused
Config Hex Char 1	Unused

Config Hex Char 2

<u>Bit</u>	<u>Meaning</u>
0	Output Format (0= ASCII, 1=Binary)
1	Output Units (0=Inches, 1= Centimeters)
2	Unused
3	Transmit Mode (0 = Polled, 1 = Continuous)

Output List Record

This record is sent in response to a *O{stationNum}<>* command. It returns the list of currently selected output parameters for that station, 2 bytes per item.

2{stationNum}O{par1par2...parN}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '2'
2	Station Number
3	Sub-Record type, 'O'
4-5	<i>par1</i>
6-7	<i>par2</i>
...	CR, LF

For example, the default data list would be returned as:
'21O 2 4 1<>'

Station State Record

This record is sent in response to a $l\{stationNum\}\langle\rangle$ command. *StationNum* is ignored and the record returns the state of the first four stations. This maintains the compatibility with the Fastrak™ protocol.

Output values of are interpreted as 1 for ON and 0 as OFF.

$2\{stationNum\}l\{stat1stat2stat3stat4\}\langle\rangle$

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '2'
2	Station Number. 1, 2, 3, 4
3	Sub-Record type, '1'
4	State of station 1
5	State of station 2
6	State of station 3
7	State of station 4
8,9	CR, LF

Alignment Reference Frame Record

This record is sent in response to an $A\{stationNum\}\langle\rangle$ command. It returns 9 ASCII floats that were last set with the *A* command. Each float is represented as 7 characters with 2 digits after the floating point.

$2\{stationNum\}A\{OxOyOzXxXyXzYxYyYz}\langle\rangle$

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '2'
2	Station Number
3	Sub-Record type, 'A'
4-24	<i>OxOyOz</i> - origin coordinates
25-45	<i>XxXyXz</i> - vector in the direction of the positive x axis
46-66	<i>YxYyYz</i> - vector in the direction of the positive y axis
67-68	CR, LF

Boresight Reference Angles Record

This record is sent in response to a $G\{stationNum\}<>$ command. It returns 3 ASCII floats that were last set with the G command. Each float is represented as 7 characters with 2 digits after the floating point.

$2\{stationNum\}G\{yawref\ pitchref\ rollref\}<>$

<u>Bytes</u>	<u>Explanation</u>
1	Record type, '2'
2	Station Number
3	Sub-Record type, 'G'
4-10	$yawref$ - azimuth reference angle
11-17	$pitchref$ - elevation reference angle
18-24	$rollref$ - roll reference angle
25-26	CR, LF

Hemisphere Record

This record is sent in response to a $H\{stationNum\}<>$ command. It returns 3 ASCII floats that were last set with the H command. Each float is represented as 7 characters with 2 digits after the floating point.

$2\{stationNum\}H\{p1p2p3\}<>$

5.3.3 InterSense-specific Records.

Manufacturer System Status Record

This record is sent in response to an *MS*<> command. It returns a status record specific to the InterSense system.

31S{statusRecord}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '3'
2	Station number. Always '1'
3	Sub-Record type, 'S'
4	Config Hex Char 0
5	Config Hex Char 1
6	Config Hex Char 2
7,8	CR, LF

To decode each of the Config Hex Characters

Config Hex Char 0 Reserved

Config Hex Char 1

<u>Bit</u>	<u>Meaning</u>
0	Reserved
1	Reserved
2	Unused
3	Unused

Config Hex Char 2

<u>Bit</u>	<u>Meaning</u>
0	Reserved
1	Boresight Compatibility Mode (0= Firmware Version 2.x, 1=FASTRACK™)
2	Time units (0 = <i>milliseconds</i> , 1 = <i>microseconds</i>)
3	Unused

Manufacturer Station Record

This record is sent in response to the *Ms{stationNum}<>* command. It returns a station status record specific to the InterSense system.

3{stationNum}s{statusRecord}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '3'
2	Station number
3	Sub-Record type, 's'
4	Config Byte 0
5	Config Byte 1
6	Config Byte 2
7,8	CR, LF

To decode each of the Config bytes

Config Byte 0	Unused
Config Byte 1	Corresponds to the Perceptual Enhancement Level. Can be 0, 1, or 2. The remaining 2 bits are reserved for future expansion of this option.
Config Byte 2	

<u>Bit</u>	<u>Meaning</u>
0	Reserved
1	Heading Compensation Mode (0 = OFF, 1 = ON)
2	Unused
3	Reserved

InertiaCube Record

This record is sent in response to the *MCI{station number}<>* command. It returns the number of the InertiaCube currently associated with this station.

3{station number}I{InertiaCube number}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '3'
2	Station Number
3	Sub-Record type, 'I'
4-5	InertiaCube number. 1-4 or -1 if none are associated.
6,7	CR, LF

Prediction Interval Record

This record is sent in response to *Mp{stationNum}<>* command. It returns an ASCII integer for the number of milliseconds of prediction.

3{stationNum}p{interval}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '3'
2	Station Number
3	Sub-Record type, 'p'
4	Prediction interval
5,6	CR, LF

Sensitivity Level Record

This record is sent in response to *MQ{station number}<>* command. It returns the current sensitivity settings of a station. This setting is only relevant when Perceptual Enhancement level is 2.

3{Station Number}Q{Sensitivity Level}<>

<u>Bytes</u>	<u>Explanation</u>
1	Record type , '3'
2	Station Number
3	Sub-Record type, 'Q'
4	Sensitivity level 1 to 5
5,6	CR, LF

A Appendix A - Frequently Asked Questions

Q1. What is the maximum length of the cable between the InertiaCube and the Base Unit?

The cable between the InertiaCube and the Base Unit has been tested to a length of 30 feet. Longer than 30 feet will result in loss of signal strength.

Q2. Does the InertiaCube have batteries? How often do they have to be changed?

The InertiaCubes do not contain batteries.

Q3. Are all the interconnection cables shielded?

YES

Q4. What is the MTBF of each component separately?

Based on supplier data, the MTBF for the system is estimated at 5 years.

Q5. What type of shock can the InertiaCube sustain?

These InertiaCube is designed to withstand a maximum acceleration of 500 g. Basically this means that a direct impact on the devices is not recommended. The InertiaCubes can withstand a higher level of shock if installed on the inside of an object, or mounted on rubber.

Q6. What are the PIN assignments on the DB9 on the IS-300?

Pin	Function
1	DCD
2	RX
3	TX
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

To connect up to a Mini-DIN 8 (Mac's & SGI's) or a DB-25 serial port, use this table:

<u>InterSense signal</u>	<u>InterSense (DB9)</u>	<u>DIN 8</u>	<u>DB-25</u>
RX	2	3 (TX)	3 (TX)
TX	3	5 (RX)	2 (RX)
GND	5	4 (GND)	7 (GND)

Note that you must connect up RX→TX and TX→RX. So the bottom line is that you only need three wires; RX, TX, and GND.

Q7. Do you have any advice about working with software packages?

Some software packages (such as Sense8) will not work if more than one sensor is turned on. We recommend that you turn off all sensors except one and save the settings.

Q8. How do I know whether I have the latest release of ISDEMO?

Check our web site, the URL is <http://www.isense.com/support.html> Click on the ISDEMO.ZIP hypertext link. We always post the latest release for you to download.

B Appendix B – Troubleshooting

<u>Problem</u>	<u>Reason/Solution</u>
ISDEMO doesn't work!	Most common reasons (not in any order): <ol style="list-style-type: none">1) Not using a <i>NULL</i> modem cable.2) Connected to wrong Com port plug on the back of the computer.3) The selected serial port is captured by another program and can't be opened by ISDEMO.4) Serial port not capable of running at desired baud rate. This is usually due to older computers that cannot run at 115200 baud. The problem is a lack of a proper UART such as the 16550.5) Incorrect port settings - use <i>autodetect</i> for Com parameters.6) Not using <i>Start Displaying Data</i>. It may be necessary to select <i>Stop Displaying Data</i> first.7) At least one of the following must be turned on under the Display Menu: Numeric Display, Display Sensor.
ISDEMO is communicating, but system does not track	Check for the following: <ol style="list-style-type: none">1) The InertiaCube is not plugged in.2) The InertiaCube was plugged in <i>after</i> power up.3) Selecting the wrong Sensor #.
InertiaCube interference	Check for the following: <ol style="list-style-type: none">1) Placement directly on top of metal. You should place the InertiaCube an inch or two away.
Orientation is drifting uncontrollably	<ol style="list-style-type: none">1) Make sure that InertiaCube is properly plugged in.2) Keep InertiaCube still while the tracker is booting up or after reconfiguring it.

C Appendix C – Health and Safety warnings and guidelines

Important:

Most of the side effects described in this section usually only occur when a tracking device, like an IS-300, is used with personal displays or 3D glasses. The symptoms listed below are usually referred to as “Simulator Sickness”.



Read and follow the user instructions.

Before using IS-300, read and follow the user instructions. In exceptional circumstances, failure to read and follow the user instructions could result in possible side effects that may lead to accidental injury during or after use.



Recommended.

For use only by persons 15 years of age or older. This system should not be used by:

- Persons under the influence of drugs and alcohol.
- Pregnant women.
- Persons suffering from a heart condition
- Persons with a history of epilepsy.



Take frequent breaks.

It is recommended that IS-300 should be used for no more than one hour at a time. After that you should take a 15-minute rest break before re-use regardless of how you feel. If you feel uncomfortable at any time, stop using immediately.



Rest after using.

Rest for at least 15 minutes after using IS-300 even if you feel fine and have experienced none of the symptoms described below. If you have experienced any undesirable effects or symptoms, rest until they are completely gone. Do not walk, drive, ride a bike or operate equipment until you have rested, otherwise you risk injury to yourself and others.



Epilepsy and seizures.

A very small part of the population has a condition that may result in epileptic seizures or loss of consciousness. If you or anyone in your family has epilepsy or has experienced seizures or loss of consciousness, do not use IS-300 without first consulting your physician. Persons who have not experienced seizures or loss of consciousness may still have an epileptic condition. We recommend that a non-user is always present when IS-300 is being used.



Additional possible risks of harm.

While tracking technology has been used for many years, the range of sensors that are used to calculate positional and angular data continues to develop. Over the last twenty years a considerable amount of research has been conducted into possible side effects induced in users of real time computing systems that include various types of tracking sensors. This research has reported the symptoms described below from some users of these systems.

IS-300 has been designed using the latest sensor technologies and we believe that the possibility of such symptoms occurring has been minimized. However, it is not possible to design for the individual characteristics of each user and it is possible that users will experience one or more of the side effects described below. Historic research shows that the effects or symptoms ordinarily occur during and immediately after use and should diminish quickly once the user stops using the system.

We want you to make an informed and responsible choice about using the IS-300. Accordingly, we warn you that even if you read and follow the User Instructions, you may experience one or more of the following effects or symptoms if you use IS-300 with a personal display: eye strain, altered vision, eye or muscle twitching, headaches, neck and shoulder strain, nausea and vomiting, disorientation, dizziness, impaired balance and stability, drowsiness, fainting, fatigue, sweating, extreme paleness, impaired hand-eye or other co-ordination.

Each effect or symptom, if it occurs, should be temporary and may last from a few minutes to 30 minutes.

D Appendix D. Interface Protocol Commands – Quick Reference

Command	Syntax	Page
Data Record Request	<i>P</i>	30
Output mode	<i>C, c</i>	30
Alignment Reference Frame	<i>A{stationNum},[Ox,Oy,Oz, Xx, Xy, Xz, Yx, Yy, Yz]<></i>	30
Reset Alignment Reference Frame	<i>R{stationNum}<></i>	31
Boresight Reference Angles	<i>G{stationNum},[yawref, pitchref, rollref]<></i>	31
Boresight Compatibility Mode	<i>MBF<></i> Switch to Fastrak™ Compatible mode. <i>MBI<></i> Switch to Version 2.x Compatible mode.	31
Boresight	<i>B{stationNum}<></i> (Fastrak™ compatibility mode) <i>MB{stationNum}<></i> (Version 2.x compatibility mode)	31
Unboresight	<i>b{stationNum}<></i> (Fastrak™ compatibility mode) <i>Mb{stationNum}<></i> (Version 2.x compatibility mode)	32
Heading Boresight	<i>B{stationNum}<></i> (Version 2.x compatibility mode) <i>MB{stationNum}<></i> (Fastrak™ compatibility mode)	32
Heading Unboresight	<i>b{stationNum}<></i> (Version 2.x compatibility mode) <i>Mb{stationNum}<></i> (Fastrak™ compatibility mode)	32
Set Communication Parameters	<i>o{rate,parity,bits,HHS}<></i>	32
System Record Request	<i>S</i>	33
Station Status	<i>l{stationNum},[state]<></i>	33
Output Units Control	<i>U</i> Set units to inches. <i>u</i> Set units to centimeters.	33
System control	<i>^K</i> Save the current settings to nonvolatile memory. <i>W</i> Restore to the factory defaults. <i>^Y</i> Restart the firmware to the power up condition. <i>^S</i> Suspend data transmission. <i>^Q</i> Resume data transmission.	33

Output record mode	<i>F</i> Put in ASCII output mode.	33
	<i>f</i> Put in Binary output mode.	
Output record list settings	<i>O{stationNum},[p1],[p2],[p3],.....,[pn]<></i>	34
Hemisphere	<i>H{stationNum},[p1,p2,p3]<></i>	36
Time Units	<i>MT<></i> Sets to milliseconds.	37
	<i>Mt<></i> Sets to microseconds.	
Set Current Time to Zero	<i>MZ<></i>	37
InterSense System Status Record Request	<i>MS<></i>	37
Tracking Status Record Request	<i>MP<></i>	38
InterSense Station Status Record Request	<i>Ms{stationNum}<></i>	38
Compass Heading Correction	<i>MH{stationNum}<></i> Compass ON	38
	<i>Mh{stationNum}<></i> Compass OFF	
Prediction Interval	<i>Mp{stationNum},[interval]<></i>	38
Perceptual Enhancement Level	<i>MF{stationNum},{Mode}<></i>	39
Rotational Sensitivity Level	<i>MQ{stationNum},[Sensitivity Level]<></i>	39
Associate InertiaCube with a Station	<i>MCI{stationNum},[InertiaCube number]<></i>	40
Disassociate InertiaCube from a Station	<i>MCi[stationNum, InertiaCube number]<></i>	40
Apply New Configuration	<i>MCE<></i>	40
Cancel Configuration Session	<i>MCx<></i>	40

E Appendix E – Index of Terms

I

16 bit binary format *See* Binary 16 format

A

Alignment Reference Frame
 commands 30, 54
 record 44
Apply Configuration
 command 40, 55
ASCII format
 command 33, 55
 data record 42
 ISDEMO 21
Autodetect communications 20

B

Base Unit 12
 mode switch 15
 set-up 15
Baud Rate
 command 32, 54
 ISDEMO 20
 mode switch 15
Binary 16 format 35
Binary format
 command 33, 55
 data record 42
 ISDEMO 21
Boresight
 commands 31, 54
 compatibility with Fastrak™ 31, 54
 ISDEMO 19
 record 45

C

Centimeters 43
Communications
 auto-detecting 20
 command 32, 54
 ISDEMO 20
Compass 7
 command 38, 55
 ISDEMO 23
Compatibility 11
Continuous Mode
 command 30
 data records 42
 system status record 43
Coriolis 6
CR (carriage return) 30

D

Data
 capture 29
 format
 command 54
 ISDEMO 21
 output record 42
Direction Cosines 35
Display Text 26
DOS
 ISDEMO 26
 ISDEMO window management 16, 29
 sample code 13

F

Fastrak™ 10, 30
File menu 18
Firmware version 43

G

GEOS Mode	
configuring	23
description.....	7

H

Heading Boresight.....	32, 54
Help	29
Hemisphere	
command	36, 55
record	45

I

IEEE.....	21
Inches.....	43
InertiaCube	
assignment.....	40, 47, 55
care	13
ISDEMO	23
placement recommendations.....	14
technology overview	6
IS-300	17
IS-600	17
IS-900	17

L

LF (line feed)	30
Load and Save Factory Settings.....	19
Load Power Up Settings.....	19

M

Magnetometer	<i>See</i> Compass
Mode Switch	15

N

NT	13
Numeric Display.....	26

O

Output Mode	
commands	30
ISDEMO	21
system status record.....	43
Output Record List	
command.....	34, 55
record.....	43
Output Units.....	43

P

Perceptual Enhancement	
algorithm.....	9
command.....	39, 55
ISDEMO	23
Polled Mode	
command.....	30
data records	42
system status record.....	43
Prediction	
command.....	38, 55
record.....	48

Q

Quaternion	34, 35
------------------	--------

R

Refresh	24
Rotation Matrix	35
Rotational Sensitivity	<i>See</i> Sensitivity
RS-232	
Pin assignment	49
settings	20, 32, 54

S

Save Current Settings.....	19
Send Command File	28
Send Command String.....	27
Sensitivity	
command.....	39, 55
ISDEMO	24
record.....	48
Shortcut Keys	29
Software	
compatibility	11
ISDEMO	13, 16
Start Displaying Data	25
Station	
configuration.....	23

state record.....	44
state, command.....	33, 54
Stop Displaying Data.....	25
Synchronize to monitor	26
System Information.....	28
System Initialization window.....	18

T

Time Stamp	42
Time Units.....	37, 46, 55
Tools.....	27
Tracker System Parameters	21
Transformation Matrix.....	<i>See</i> Rotation Matrix

U

Unboresight	
command.....	32, 54
ISDEMO	19
UNIX.....	13

W

Win32/NT sample code	13
----------------------------	----

Y

Yaw Boresight.....	<i>See</i> Heading Boresight
--------------------	------------------------------