

MWA ASC Module Build Instruction

Assembly Details

1. Insert the ASC PCB into the housing and fix in place using the fixings supplied.
2. Attach the Front Panel metalwork using the fixings supplied.
3. Assemble the housing, pins and wire for the Cable MWA-3007 P100.
4. Attach the D-Type Connectors 3W3 and 9W plus 40A sockets to the ASC assembly using the fixings provided.
5. Attach the interconnecting wires between P1 and C1, use heat shrink were appropriate.
6. Attach the P100 housing and wires to P1 and C1, use heat shrink were appropriate.
7. Secure CAB-07 with cable tie as shown.
8. Attach RF cables MWA-3003 to the PCB and Front Panel, using the fixings supplied.
9. The assembly instructions for CAB-07 can be found in the cable drawing for that cable.